

A.3.0137
Driver of water pump centrifuge

A.3.0177 (6121.07.090)
Driver of water pump sealing ring

A.3.0136
Base for extraction of water pump impeller

A.5.0115
Spark plug wrench

A.2.0121
Tool for supporting valves

A.3.0134
Valve guide puller

A.3.0146
Driver for front cover oil seal ring

A.3.0178 (6121.07.293)
Driver for rear crankshaft oil seal ring

A.2.0128
Fastening spacer for goniometer

C.6.0111
Goniometer for time setting

A.2.0127
Goniometer pointer for time setting

A.3.0155
Guide for fitting of circlip of water pump centrifuge

A.3.0147
Water pump pulley puller

A.3.0133
Driver of valve guides

A.2.0108
Tool for cylinder head support

A.2.0122
Tool for turning crankshaft

A.2.0103
Caulking tool for plugs of crankshaft oil ducts

A.5.0103
Wrench for turning camshaft

A.3.0103/1
Lever for removing valve cotters

A.3.0103/2
Lever support for removing valve cotters

A.3.0103/6
Lever retainer for removing valve cotters

C.5.0111 with C.5.0116
Support for checking of valve cups

A.2.0120
Support for timing checking dial gauge

A.5.0108
Wrench for rear nuts securing carburetor

A.4.0103
Clutch disc centering spindle

C.6.0104
Clutch overhauling tool

A.5.0133 (6121.18.021)
Wrench for nuts securing intake manifold

A.3.0142
Puller for oil pressure valve

C.8.0100
Ring for zero-setting of cylinder barrel diameter inspection gauge

A.5.0106
Wrench for oil drain plugs

A.2.0060
Wrench for sump bottom screws

A.5.0124
Wrench for nuts securing oil filter support

A.5.0127
Wrench for nut securing transmission fork

A.3.0180 (6121.07.464)
Driver for rear cover oil seal ring

A.2.0117
Tool for retaining cylinder barrels

A.3.0182 (6121.04.002)
Tool for removal of main bearing caps

A.3.0139/1
Lever for removal of rear main bearing cap

A.3.0139/2
Tool for removal of rear main bearing cap

A.3.0113
Tool for driving rubber plugs into crankcase

A.3.0143
Puller of idler gear bush from crankcase

A.4.0112
Guide for reaming of idler gear bushes

A.2.0124
Tool for removing and refitting flexible joint

A.3.0114
Tool for protection of oil seal ring of clutch housing

A.3.0185 (6121.01.504)
Primary shaft retaining clamp

C.6.0116 (673.5647)
Setting gauge for synchronizer control sleeves

A.3.0118
Puller-driver of silentblock

A.3.0182 (6121.04.002)
Tool for removal of main bearing caps

A.3.0139/1
Lever for removal of rear main bearing cap

A.3.0139/2
Tool for removal of rear main bearing cap

A.3.0113
Tool for driving rubber plugs into crankcase

A.3.0143
Puller of idler gear bush from crankcase

A.4.0112
Guide for reaming of idler gear bushes

A.2.0124
Tool for removing and refitting flexible joint

A.3.0114
Tool for protection of oil seal ring of clutch housing

A.3.0185 (6121.01.504)
Primary shaft retaining clamp

C.6.0116 (673.5647)
Setting gauge for synchronizer control sleeves

A.3.0118
Puller-driver of silentblock



SPECIAL TOOLS FOR CAR GIULIA 1600 T.I.

ENGINE - CLUTCH - GEARBOX
PROPELLER SHAFT

LOT	A	CONSISTING OF TOOLS MARKED WITH	A
B	B	(PLUS LOT	A)
C	C	(PLUS LOT	A AND B)
D	D	(PLUS LOT	A, B AND C)

- TOOLS APPLICABLE ALSO TO "GIULIETTA", MODEL
- TOOLS APPLICABLE ALSO TO "2000", MODEL
- TOOLS APPLICABLE ALSO TO "2600", MODEL

As a reference, previous order numbers are given in brackets; these numbers should be born in mind when ordering to avoid the purchase of duplicate tools.